

Pulse Skate CRS700/710 Kids Shoe Size			
US Size	Euro Size	Inches	Millimeters
J13	33	8.15	207
1	34	8.43	214
2	35	8.7	221
3	36	8.98	228
4	37	9.21	234
5	38	9.45	240
6	39	9.96	253
7	40	10.24	260
8	41	10.51	267